

Each of the 4 posts on the Covana must be properly anchored to the foundation using at least one of the pre-drilled holes located on the foot of each post.

- Use a 1/4" (6mm) concrete anchor for concrete pads or a 1/4" (6mm) lag bolt for wood foundations. Minimum of 1-1/4" (30mm) long

